



飞宇蝎子-C镜头兼容列表

相机品牌	相机型号	相机尺寸	镜头型号	镜头尺寸	安装方式	横拍安装调平情况		竖拍安装调平情况		备注					
						短焦距	长焦距	短焦距	长焦距						
索尼	a1 a9 a9 III (A7M3) a7R a7R III a7S a7S II a7S III a7R II (A7M2) a7 II (A7M2)	a1 128.9×96.9×80.8mm 652g a9 126.9×95.6×63.0mm 588g a9 III 128.9×96.4×77.5mm 678g a7R 126.9×94.4×48.2mm 407g a7R III 126.9×95.6×62.7mm 572g a7S 126.9×94.4×48.2mm 446g a7S II 126.9×95.7×60.2mm 584g a7S III 128.9×96.9×80.8mm 614g a7R II 126.9×95.7×60.3mm 582g a7 II 126.9×95.7×59.7mm 556g	E 10 -18mm F4 OSS	Φ70mm*63.5mm 225g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 12-24mm F4 G	Φ87mm*117mm 565g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 16-35mm F2.8 GM	Φ89mm*122mm 680g	单机+镜头 搭配单反相机	√	√	—	—						
			FE16-35mm f/4 ZA OSS	Φ78mm*99mm 518g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 24-70 F2.8 GM	Φ87.6mm*136mm 886g	单机+镜头 搭配单反相机	√	√	—	—						
			Zeiss E 16-70 F4 OSS	Φ66.6mm*75mm 308g	单机+镜头 搭配单反相机	√	√	—	—						
			E PZ 18 -105mm F4 G OSS	Φ78mm*110mm 427g	单机+镜头 搭配单反相机	√	√	—	—						
			E PZ 18 -200mm F3.5-6.3 OSS LE	Φ93.2mm*99mm 649g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 4/24-105 G OSS	Φ83.4mm*113.3 mm 663g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 28-70mm f/3.5-5.6 OSS	Φ72.5mm*83mm 295g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 28mm F2	Φ64mm*60mm 200g	单机+镜头 搭配单反相机	√	√	—	—						
			Zeiss FE 35mm F2.8 ZA	Φ61.5mm*36.5mm 120g	单机+镜头 搭配单反相机	√	√	—	—						
			Sigma 30mm f/1.4 DC DN	Φ64.8mm*73.3mm 265g	单机+镜头 搭配单反相机	√	√	—	—						
			Sigma 35mm f1.4 DG HSM Art	Φ77mm*94mm 665g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 55mm F1.8	Φ64mm*71mm 281g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 50mm F2.8 MACRO	Φ71mm*71mm 236g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 85mm F1.4 GM	Φ89.5mm*107.5mm 820g	单机+镜头 搭配单反相机	√	√	—	—						
			Vario-Tessar FE 24-70mm F4 ZA OSS	Φ73mm*94.5mm 426g	单机+镜头 搭配单反相机	√	√	—	—						
			FE PZ 16-35mm F4 G	Φ80.5mm*88.1mm 353g	单机+镜头 搭配单反相机	√	√	√	√	横装需增高块; 竖装需镜头支架架 横装需增高块					
			FX3	FX3 77.8×129.7×84.5mm 640g	TAMRON 28-75mm f/2.8 Di III RXD (A036)	Φ117.6mm*75.8mm 550g	单机+镜头 搭配单反相机	√	√	—	—	横拍需要安装增高块、镜头支架			
	a7 IV (A7M4)	a7M4 129.0×97.0×81.0mm 699g	FE 24-240mm F3.5-6.3 OSS	Φ119*81mm 780g	单机+镜头 搭配单反相机	√	√	—	—						
			FE 50mm f/1.8	Φ68.6mm*59.5mm 186g	单机+镜头 搭配单反相机	√	√	×	×						
	A7R4 A7RMAA	A7R4 128.9×96.4×77.5mm 665g A7RMAA 128.9×96.4×77.5mm 580g	FE 24-105mm f/4 G OSS	Φ83.4mm*113.3mm 663g	单机+镜头 搭配单反相机	√	√	√	√	横装需使用增高块, 长焦还需使用镜头支架架; 竖装不需要增高块, 长焦需镜头支架架					
			sanyang 1.5/35mm	Φ77mm*137.5mm 720g	单机+镜头 搭配单反相机	√	√	×	×	需使用增高块					
	A7C	A7C 124×71.1×59.7mm 509g	FE 28-60mm f/4-5.6	Φ67mm*45mm 167g	单机+镜头 搭配单反相机	√	√	×	×	横拍需使用增高块					
	RX10 III (RX10M3) RX10 IV (RX10M4)	RX10M3 132.5×94×127.4mm 1095g RX10M4 132.5×94×127.4mm 1095g			单机+镜头 搭配单反相机	√	√	√	√	横拍需使用增高块, 镜头支架架, 竖拍需镜头支架架					
	松下	a5100 a6000 a6100 a6300 a6400 a6500 a6600	a5100 109.6×62.8×35.7 224g a6000 120×66.9×45.1mm 285g a6100 120×66.9×49.9mm 396g a6300 120×66.9×48.8mm 361g a6400 120×67×60mm 379g a6500 120×66.9×53.3mm 410g a6600 120×66.9×59mm 503g	E 10 -18mm F4 OSS	Φ70mm*63.5mm 225g	单机+镜头 搭配单反相机	√	√	—	—					
				FE 12-24mm F4 G	Φ87mm*117mm 565g	单机+镜头 搭配单反相机	√	√	—	—					
				FE 16-35mm F2.8 GM	Φ89mm*122mm 680g	单机+镜头 搭配单反相机	√	√	—	—					
				FE16-35mm f/4 ZA OSS	Φ78mm*99mm 518g	单机+镜头 搭配单反相机	√	√	—	—					
				FE 24-70 F2.8 GM	Φ87.6mm*136mm 886g	单机+镜头 搭配单反相机	√	√	—	—					
				Vario-Tessar FE 24-70mm F4 ZA OSS	Φ73mm*94.5mm 426g	单机+镜头 搭配单反相机	√	√	—	—					
Zeiss E 16-70 F4 OSS				Φ66.6mm*75mm 308g	单机+镜头 搭配单反相机	√	√	—	—						
E PZ 18 -105mm F4 G OSS				Φ78mm*110mm 427g	单机+镜头 搭配单反相机	√	√	—	—						
E PZ 18 -200mm F3.5-6.3 OSS LE				Φ93.2mm*99mm 649g	单机+镜头 搭配单反相机	√	√	—	—						
FE 4/24-105 G OSS				Φ83.4mm*113.3 mm 663g	单机+镜头 搭配单反相机	√	√	—	—						
FE 28-70mm f/3.5-5.6 OSS				Φ72.5mm*83mm 295g	单机+镜头 搭配单反相机	√	√	—	—						
FE 28mm F2				Φ64mm*60mm 200g	单机+镜头 搭配单反相机	√	√	—	—						
Zeiss FE 35mm F2.8 ZA				Φ61.5mm*36.5mm 120g	单机+镜头 搭配单反相机	√	√	—	—						
Sigma 30mm f/1.4 DC DN				Φ64.8mm*73.3mm 265g	单机+镜头 搭配单反相机	√	√	—	—						
Sigma 35mm f1.4 DG HSM Art				Φ77mm*94mm 665g	单机+镜头 搭配单反相机	√	√	—	—						
FE 55mm F1.8				Φ64mm*71mm 281g	单机+镜头 搭配单反相机	√	√	—	—						
FE 50mm F2.8 MACRO				Φ71mm*71mm 236g	单机+镜头 搭配单反相机	√	√	—	—						
FE 28-70mm f/3.5-5.6 OSS				Φ72.5mm*83mm 295g	单机+镜头 搭配单反相机	√	√	—	—						
FE 85mm F1.4 GM				Φ89.5mm*107.5mm 820g	单机+镜头 搭配单反相机	√	√	—	—						
E 18-135mm F3.5-5.6 OSS				Φ67.2mm*88mm 325g	单机+镜头 搭配单反相机	√	√	√	√		需使用增高块				
E PZ 16-50mm f/3.5-5.6 OSS		Φ64.7mm*29.9mm 116g	单机+镜头 搭配单反相机	√	√	×	×		需增高块						
RX100 III (RX100M3) RX100 IV (RX100M4) RX100 V (RX100M5) RX100M5A RX100 VI (RX100M6) RX100 VII (RX100M7)		RX100 III 101.6×58.1×41.0mm 290g RX100 IV 101.6×58.1×41.0mm 298g RX100 V 101.6×58.1×41.0mm 299g RX100M5A 101.6×58.1×41.0mm 299g RX100 VI 101.6×58.1×42.8mm 301g RX100 VII 101.6×58.0×42.8mm 302g			单机	√	√	—	—						
ZV-1		ZV-1 105.5×60×43.5mm 294g			单机	√	√	—	—						
FDR-AX60		FDR-AX60 73mm x 80.5mm x 173mm 535g			DV机	√	√	×	×						
ZV-E10		ZV-E10 115*64*45mm 343g	E PZ 16-50/3.5-5.6 OSS	Φ64.7mm*29.9mm 116g	单机+镜头	√	√	—	—	需使用增高块					
DSC-WX500		DSC-WX500 101.6×58.1×35.5mm 236g			单机	√	√	×	×						
DSC-HX90		DSC-HX90 102.0×58.1×35.5mm 245g			单机	√	√	×	×						
FDR-AX700		FDR-AX700 116×89.5×196.5mm 935g			DV机	√	√	×	×						
尼康		Z6 Z6 II Z7 Z7 II	Z6 134×100.5×67.5mm 675g Z6 II 134×100.5×69.5mm 615g Z7 134×100.5×67.5mm 675g Z7 II 134×100.5×67.5mm 705g	LEICA DG SUMMILUX 15mm f/1.7 ASPH	Φ58*36*46mm 115.00g	单机+镜头 搭配单反相机	√	√	—	—					
				LEICA DG SUMMILUX 25mm f/1.4 ASPH	Φ77.7mm*75mm 510g	单机+镜头 搭配单反相机	√	√	—	—					
				LEICA DG MACRO 45mm f/2.8 OIS	Φ63mm*62.5mm 225g	单机+镜头 搭配单反相机	√	√	—	—					
				LEICA DG Vario-Elmarit 8-18mm f/2.8-4.0 ASPH	Φ73.4mm*88mm 315g	单机+镜头 搭配单反相机	√	√	—	—					
	LEICA DG Vario-Elmarit 12-60 f/2.8-4 Power OIS			Φ68mm*86mm 320g	单机+镜头 搭配单反相机	√	√	—	—						
	LUMIX G X Vario 12-35mm f/2.8 II ASPH POWER OIS (H-HS12035X I代)			Φ68mm*74mm 305g	单机+镜头 搭配单反相机	√	√	×	×		需加增高块				
	M ZUIKO DIGITAL ED 12mm f/2.0			Φ56mm*43mm 130g	单机+镜头 搭配单反相机	√	√	—	—						
	LUMIX G 14-140mm f/4-5.8 OIS			Φ70mm*84mm 460g	单机+镜头 搭配单反相机	√	√	—	—						
	OLYMPUS M ZUIKO DIGITAL 12-40mm			Φ70*84mm 382g	单机+镜头 搭配单反相机	√	√	—	—						
	S5			S5 132.6×97.1×81.9mm 714g	LUMIX S 24-105mm F4	Φ84mm*118mm 680g	单机+镜头 搭配单反相机	√	√	—	—				
	GH6			GH6 138.4*100.3*99.6mm 823g	LEICA DG Vario-Elmarit 12-60mm f/2.8-4 Power OIS	Φ68mm*86mm 320g	单机+镜头 搭配单反相机	√	√	×	×	需使用镜头支架架			
	尼康			Z6 Z6 II Z7 Z7 II	Z6 134×100.5×67.5mm 675g Z6 II 134×100.5×69.5mm 615g Z7 134×100.5×67.5mm 675g Z7 II 134×100.5×67.5mm 705g	NIKKOR Z 35mm f/1.8	Φ73mm*86mm 370g	单机+镜头 搭配单反相机	√	√	—	—			
						18-140mm f/3.5-5.6 ED VR	Φ78mm*97mm 490g	单机+镜头 搭配单反相机	√	√	√	√	横拍需要安装增高块		
						NIKKOR Z 50mm f/1.8 S	Φ76mm*86.5mm 415g	单机+镜头 搭配单反相机	√	√	—	—			
						NIKKOR Z 24-70mm f/4 S	Φ77.5mm*88.5mm 500g	单机+镜头 搭配单反相机	√	√	—	—			
						NIKKOR Z 14-30mm f/4 S	Φ85mm*89mm 485g	单机+镜头 搭配单反相机	√	√	—	—			
						NIKKOR Z 28mm f/2.8	Φ71.5mm*43mm 160g	单机+镜头 搭配单反相机	√	√	×	×		横装需加增高块	
						NIKKOR Z 微距 50mm f/2.8	Φ74.5mm*66mm 260g	单机+镜头 搭配单反相机	√	√	×	×		横装需增高块	
						Z 50	Z50 126.5×93.5×60mm 395g	NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Φ70mm*32mm 135g	单机+镜头	√	√	—	—	
						Zfc	Zfc 134.5×93.5×43.5mm 445g	NIKKOR Z DX 16-50mm f/3.5-6.3 VR	Φ70mm*32mm 135g	单机+镜头	√	√	—	—	
		D7500	D7500 135.5×104×72.5mm 720g			尼康尼克尔 18-140mm f/3.5-5.6 ED VR	Φ78mm*97mm 490g	单机+镜头 搭配单反相机	√	√	√	√	长焦需加镜头支架架 长焦需加镜头支架架		
		D850	D850 146×124×78.5mm 1005g			尼康AF-S 尼克尔 24-120mm f/4G ED VR	Φ84mm*103.5mm 710g	单机+镜头 搭配单反相机	√	√	×	×			
		Z5	Z5 134×100.5×69.5mm 675g			尼克尔 Z 微距 50mm f/2.8	Φ74.5mm*66mm 260g	单机+镜头 搭配单反相机	√	√	×	×	横装需加增高块		
	Z30	Z30 128 x 73.5 x 59.5mm 405g	尼克尔 Z DX 16-50mm f/3.5-6.3 VR	Φ70mm*32mm 135g	单机+镜头 搭配单反相机	√	√	×	×	需增高块					
	佳能	EOS R EOS RP EOS R6	EOS R 135.8×98.1×87.4mm 660g EOS RP 132.5×85×70mm 485g EOS R6 138.4×97.5×88.4mm 598g	RF 35mm F1.8 MACRO IS STM	Φ74.4mm*62.8mm 305g	单机+镜头 搭配单反相机	√	√	×	×					
				EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm*102mm 595g	单机+镜头 搭配单反相机	×	×	—	—					
				EF 50mm f/1.4 DG HSM Art	Φ85mm*100mm 815g	单机+镜头 搭配单反相机	√	√	—	—					
				EF 17-40mm f/4L USM	Φ83.5mm*96.8mm 475g	单机+镜头 搭配单反相机	√	√	—	—					
				RF 50mm F1.2L USM	Φ89.8mm*108mm 950g	单机+镜头 搭配单反相机	√	√	×	×					
				RF 28-70mm F2L USM	Φ103.8mm*139.8mm 1430g	单机+镜头 搭配单反相机	√	√	—	—					
				RF 24-105mm F4L IS USM	Φ83.5mm*107.3mm 670g	单机+镜头 搭配单反相机	√	√	—	—					
				RF 15-35mm F2.8 L IS USM	Φ88.5mm*126.8mm 840g	单机+镜头 搭配单反相机	√	√	—	—					
RF50mm F1.8 STM				Φ69.2mm*40.5mm 160g	单机+镜头 搭配单反相机	√	√	×	×		俯仰轴无法调平				
EOS 80D				EOS 80D 139×105.2×78.5mm 730g	EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm*102mm 595g	单机+镜头 搭配单反相机	√	√	—	—				
EOS 6D Mark II				6D Mark II 144×110.5×74.8mm 765g	EF 24-70mm f/4L IS USM	Φ83.4mm*93mm 600g	单机+镜头 搭配单反相机	√	√	—	—				
					EF 85MM F/1.2L II USM	Φ84.0mm*91.0mm 1025g	单机+镜头 搭配单反相机	√	√	—	—				
EOS 6D				EOS 6D 144.5×110.5×71.2mm 750g	16-35mm f/2.8L II USM	Φ88.5mm*111.6mm 635g	单机+镜头 搭配单反相机	√	√	—	—				
					EF-S 18-200mm f/3.5-5.6 IS	Φ78.6mm*102mm 595g	单机+镜头 搭配单反相机	×	×	—	—				
					EF 24-105mm f/4L IS USM	Φ83.5mm*107mm 670g	单机+镜头 搭配单反相机	√	√	—	—				
EOS 200D II (250D)				EOS 200D II 122.4×92.6×89.8mm 456g	EF-S18-55mm f/4-5.6 IS STM	Φ66.5mm*61.8mm 215g	单机+镜头 搭配单反相机	√	√	—	—				
EOS 5D Mark IV				5D Mark IV 150.7×116.4×75.9mm 890g	EF 24-105mm f/4L IS USM	Φ83.5mm*107mm 670g	单机+镜头 搭配单反相机	√	√	—	—				
					EF 24-70mm f/2.8L USM	Φ83.2mm*123.5mm 950g	单机+镜头 搭配单反相机	√	√	—	—				
					EF 24-105mm f/4L IS USM	Φ83.5mm*107mm 670g	单机+镜头 搭配单反相机	√	√	—	—				
					EF 24-105 mm f/4L IS II USM	Φ88.5mm *127.5mm 795g	单机+镜头 搭配单反相机	√	√	—	—				
EOS 5D Mark III EOS 5DS R		5D Mark III 152.116.4×76.4mm 950g 5DS R 152.116.4×76.4mm 930g	EF 24-70mm f/2.8L II USM	Φ88.5mm*113											

相机品牌	相机型号	相机尺寸	镜头型号	镜头尺寸	安装方式	横拍调平情况		竖拍安装调平情况		备注
						短焦端	长焦端	短焦端	长焦端	
富士	X-T2 X-T3 X-T4	X-T2 133×92×49mm 457g X-T3 132.5×92.8×58.8mm 539g X-T4 134.6×92.8×63.8mm 607g	XF 16mm 1:1.4 R WR	Φ73mm*73mm 375g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 23mm 1:1.4 R	Φ72mm*63mm 300g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 35mm 1:1.4	Φ65mm*54.9mm 187g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 10-24mm f/4.0 R OIS	Φ78mm*87mm 410g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
	XF 16-55mm 1:2.8 R LM WR	Φ83.3mm*106.0mm 655g	单机+镜头	√	√	---	---			
	搭载单跟焦器	√	√	---	---					
	XF 18-55mm 1:2.8-4 R OIS	Φ65mm*70.4mm 310g	单机+镜头	√	√	---	---			
	搭载单跟焦器	√	√	---	---					
	XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm*98mm 490g	单机+镜头	√	√	---	---			
	搭载单跟焦器	√	√	---	---					
	X-H1	X-H1 139.8×97.3×85.5mm 673g	XF 16mm 1:1.4 R WR	Φ73mm*73mm 375g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 23mm 1:1.4 R	Φ72mm*63mm 300g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 35mm 1:1.4	Φ65mm*54.9mm 187g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 10-24mm f/4.0 R OIS	Φ78mm*87mm 410g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
	XF 16-55mm 1:2.8 R LM WR	Φ83.3mm*106.0mm 655g	单机+镜头	√	√	---	---			
	搭载单跟焦器	√	√	---	---					
	XF 18-55mm 1:2.8-4 R OIS	Φ65mm*70.4mm 310g	单机+镜头	√	√	---	---			
	搭载单跟焦器	√	√	---	---					
	XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm*98mm 490g	单机+镜头	√	√	---	---			
	搭载单跟焦器	√	√	---	---					
	X-S10	X-S10 126×85.1×65.4mm 465g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	单机+镜头	√	√	---	---	横拍需使用增高块
	搭载单跟焦器	√	√	---	---					
	X-A5 X-A7	X-A5 116.9×67.7×40.4mm 361g X-A7 119×67.7×41.1mm 320g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	单机+镜头	√	√	---	---	横拍需使用增高块
	X-T30 II	X-T30 II 118×83×47mm 383g	XC 15-45mm f/3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	单机+镜头	√	√	×	×	相机螺丝孔偏右，竖装无法安装
					搭载单跟焦器	√	√	×	×	横装需要增高块
	X-E3	X-E3 121.3×42.7×73.9mm 337g	XF18-55mm F2.8-4 R LM OI	Φ65mm*70.4mm 310g	单机+镜头	√	√	×	×	
					搭载单跟焦器	√	√	×	×	
	X100V	X100V 128×74.8×53.3mm 478g	套机	---	单机+镜头	√	√	×	×	机身太宽，竖装板不够长不能安装
					搭载单跟焦器	×	×	×	×	镜头太短，无法搭载跟焦器
	GFX 100S	GFX 100S 150×104.2×87.2mm 900g	GF 32-64mm f/4R LM WR	Φ92.6mm*145.5mm 875g	单机+镜头	√	√	×	×	横装需加增高块
					搭载单跟焦器	√	√	×	×	横装需加增高块
	X-T20 X-T30 X-T100 X-T200	X-T20 118.4×82.8×41.4mm 383g X-T30 118.4×82.8×46.8mm 383g X-T100 121.0×83.0×47.4mm 448g X-T200 121.0×83.7×55.1mm 370g	XF 16mm 1:1.4 R WR	Φ73mm*73mm 375g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 23mm 1:1.4 R	Φ72mm*63mm 300g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 35mm 1:1.4	Φ65mm*54.9mm 187g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XF 10-24mm f/4.0 R OIS	Φ78mm*87mm 410g	单机+镜头	√	√	---	---	
			搭载单跟焦器	√	√	---	---			
			XC 16-50mm f/3.5-5.6 OIS	Φ62.6mm*65.2mm 195g	单机+镜头	√	√	---	---	
搭载单跟焦器			√	√	---	---				
XF 16-55mm 1:2.8 R LM WR			Φ83.3mm*106.0mm 655g	单机+镜头	√	√	---	---		
搭载单跟焦器			√	√	---	---				
XF 18-55mm 1:2.8-4 R OIS			Φ65mm*70.4mm 310g	单机+镜头	√	√	---	---		
搭载单跟焦器			√	√	---	---				
XF 18-135mm f/3.5-5.6 R LM OIS WR	Φ76mm*98mm 490g	单机+镜头	√	√	---	---				
搭载单跟焦器	√	√	---	---						
XC 15-45mm 1:3.5-5.6 OIS PZ	Φ62.6mm*65.2mm 135g	单机+镜头	√	√	---	---				
		搭载单跟焦器	√	√	---	---				
X-H2S	X-H2S 136.3×92.9×84.6mm 660g	XF90mmF2 R LM WR	Φ75.0mm*105mm 540g	单机+镜头	√	√	√	√		
				搭载单跟焦器	√	√	√	√	横装需使用增高块	

注意：
1、“√”表示支持该选项，“×”表示不支持该选项。--为未实测。

实测不能搭载的相机+镜头组合

相机品牌	相机型号	相机尺寸	镜头型号	镜头尺寸	安装方式	横拍调平情况		竖拍安装调平情况		备注
						短焦端	长焦端	短焦端	长焦端	
索尼										
佳能	EOS-1D X Mark III	158×167.6×82.6mm 1440g	EF 70-200mm f/2.8L IS III USM	Φ88.8mm*199mm 1480g	单机+镜头	×	×	×	×	
	搭载单跟焦器	×	×	×	×					
佳能	EOS R3	EOS R3 150×142.6×87.2mm 1015g	RF28-70mm F2 L USM	Φ103.8mm*139.8mm 1430g	单机+镜头	×	×	×	×	
	搭载单跟焦器	×	×	×	×					
尼康	Z9	Z9 149×149.5×90.5mm 1340g	Nikkor Z 24-70mm f/2.8 S	Φ89mm*126mm 805g	单机+镜头	×	×	×	×	
	搭载单跟焦器	×	×	×	×					
松下	S1H	151.0×114.2×110.4mm 1164g	LUMIX S PRO 24-70mm f/2.8	Φ90.9mm*140mm 935g	单机+镜头	×	×	×	×	
	搭载单跟焦器	×	×	×	×					
适马	FP	112.6×69.9×45.3mm 422g	松下LUMIX S PRO 50mm F1.4	Φ90mm*130mm 955g	单机+镜头	×	×	×	×	
	搭载单跟焦器	×	×	×	×					
富士	X-Pro 3	140.5×82.8×46.1mm 497g	XF16mmF1.4 R WR	Φ73.4mm*73.0mm 375g	单机+镜头	×	×	×	×	显示屏向下翻转时会碰到横滚电机
	搭载单跟焦器	×	×	×	×					
Black magic design	BMPCC 6K	177.8*101.6*96.52mm 898g	EF 16-35mm f2.8L II USM	Φ88.5mm*111.6mm 640g	单机+镜头	×	×	×	×	
	搭载单跟焦器	×	×	×	×					